BASIC FILE CART BFC-1

TOOLS NEEDED FOR ASSEMBLY: PHILLIPS SCREWDRIVER, %6" OPEN END WRENCH HARDWARE INCLUDED: $\frac{1}{4}$ -20 PAN HEAD PHILLIPS SCREWS & $\frac{1}{4}$ -20 FLANGE NUTS





1.) Assemble angled shelves (if applicable). Attach the angled shelf back to the angled shelf bottom using (2) $\frac{1}{4}$ -20 flange nuts and pan head Phillips screws. Repeat step for any additional angled shelves.


2.) Attach angled shelves to cart sides (if applicable). Angled shelves use the (4) hole

PAN HEAD

4.) After cart sides and shelves are assembled, turn unit upside down and insert (4) casters

into sockets on bottom of cart.





BASIC FILE CART BFC-3

TOOLS NEEDED FOR ASSEMBLY: PHILLIPS SCREWDRIVER, $\%_6$ " OPEN END WRENCH HARDWARE INCLUDED: $\%_4$ -20 PAN HEAD PHILLIPS SCREWS & $\%_4$ -20 FLANGE NUTS


¼−20 FLANGE NUT



1.) Attach flat shelves. Flat shelves can attach with sides up or sides down (whichever is preferred). Insert $\frac{1}{4}$ -20 pan head Phillips screws into the holes in the flat shelf and then into the holes on the cart sides. Secure with flange nuts. Tighten screws only after all screws needed have been inserted. Flat shelves require (8) screws and nuts each. Cart sides can accept up to 3 flat shelves.

4-20 PAN HEAD PHILLIPS SCREW






BINDER FILE CART BFC-5 & BFC-2

TOOLS NEEDED FOR ASSEMBLY: PHILLIPS SCREWDRIVER, %6" OPEN END WRENCH HARDWARE INCLUDED: $\frac{1}{4}$ -20 PAN HEAD PHILLIPS SCREWS (20), $\frac{1}{4}$ -20 FLANGE NUTS (20), AND CASTERS (4)

- 1.) Assemble 2 set of angled shelves. Position shelf back and shelf bottom together and using (2) $\frac{1}{4}$ -20 flange nuts and pan head Phillips screws. Tighten screws.
- 2.) Attach 2 sets of angled shelves to cart sides. Attach angled shelves using (8) $\frac{1}{4}$ -20 pan head screw and (8) $\frac{1}{4}$ -20 flange nuts (4 per side, per shelf) to the cart sides, do not tighten screws until all 16 screws in both shelves have been started.



MINI FILE CART BFC-4


⅓−20 FLANGE NUT



TOOLS NEEDED FOR ASSEMBLY: PHILLIPS SCREWDRIVER, $\%_6$ " OPEN END WRENCH HARDWARE INCLUDED: $\frac{1}{4}$ -20 PAN HEAD PHILLIPS SCREWS & $\frac{1}{4}$ -20 FLANGE NUTS

 $\frac{1}{4}$ -20 PAN HEAD








3.) After cart sides and shelves are assembled, turn unit upside down and insert (4) casters into sockets on bottom of cart.

OPTIONAL BASIC FILE CART END PANELS



- 1.) Flip file cart upside down (as shown). Take end panel and with cutout down slide flange on end panel behind return bend on file cart side. Push end panel into file cart side.
- 2.) Secure end panel to file cart side using (3) #8 x $\frac{1}{2}$ " sheet metal screws inserted through the clearance slots in file cart side and into end panel.
- 3.) Repeat steps (1 & 2) for other side of cart.

- END PANEL

#8 x ½" SHEET METAL SCREW



